



Mixed packaging:roof frame and bottom frame will be packed together with bolts; all **Packaging** the wall panels packed together with wooden pallet in the bottom, corrugated board on the surface, and XPS board in the interspace. And it will be shipped in 40' container.

- 40 feet ocean freight container:
- A: Take out the small packages.
- B: Use folk lift to take out the wall panel packages.

Unloading

- C: Grapple the corner on bottom side of the container house and drage the package out, remain about 50cm in the shipping container.
- D: Use folk lift to lift the container package in the middle and move it out of the shipping container.
- E: Put the package on ground sidewise, use wooden pad if it's flatwise.

